

**WICHTIG!** Für späteres Nachschlagen aufbewahren. Sorgfältig lesen.  
**NOTE!** Please retain this information for future reference. Read carefully.

## Montageanleitung für



**KAWAsimplex**



**KAWAHPL**

Unsere Produkte entsprechen den **GU-Normen** und sind **TÜV** geprüft

### Liebe Kunden,

Sie haben einen zusammengesetzten Wandwickeltisch erhalten.

Weitere Teile sind:

- 1x Metallschiene zum Anbringen an die Wand
- 1x Wickelmatte (bereits inliegend)
- 2x Sicherungsschrauben
- 1x Inbusschlüssel
- 1x Acrylglas-Boden



Zusätzlich beim **KAWAHPL**

- 1x Acrylglas-Boden (insgesamt 2)
- 16x Regalbodenträger zum Einsetzen der Acrylglas-Böden

### Durchführung der Montage:

- Bohren Sie Löcher zur Anbringung der Wandschiene. Da es viele Wandarten gibt (Holz, Beton, Lehm, ...) ist es wichtig, dass Sie den richtigen Dübel für Ihre Wand benutzen. Erkundigen Sie sich bei einem Handwerker oder im Baumarkt nach dem richtigen Befestigungsmaterial.
- Wir empfehlen eine Arbeitshöhe von 95 cm (Fußboden/ geöffnete Wickelplatte) | siehe: [www.timkid.de/hilfe](http://www.timkid.de/hilfe)
- Hängen Sie den Wickeltisch an die Wandschiene an und befestigen Sie den Wandwickeltisch mit den 2 Sicherungsschrauben. (vorgegebene Löcher befinden sich im Korpus)

Bei **KAWAHPL** bitte beachten:

- Setzen Sie die Acrylglas-Böden ein. (Bitte vorher die Schutzfolie entfernen)
- Beachten Sie bitte, dass jeweils ein Regalbodenträger links und rechts vor einem Acrylglas-Boden gesetzt werden muss, um den Regalboden zu sichern.

### Bitte beachten Sie:

- WARNUNG:** Bitte lassen Sie Ihr Kind nicht unbeaufsichtigt!
- Bitte prüfen Sie regelmäßig, ob alle montierten Teile fest angezogen sind.
- Vermeiden Sie starke Wärmequellen in unmittelbarer Umgebung der Wickeleinrichtung (z.B. elektrische Heizstrahler, gasbeheizte Öfen, usw.)
- Für Kinder bis 15kg empfohlen | Maximalbelastung = 50 kg
- Zusätzliche Teile/ Ersatzteile nur über die Firma timkid beziehen.
- Den Wandwickeltisch bitte nicht benutzen, wenn irgendein Teil defekt/abgerissen ist oder fehlt.
- Reinigungsempfehlung für Resopal, Holzoberflächen und für die Wickelaufgabe:  
Feucht abwischen, eventuell mit handelsüblichem Desinfektionsmittel behandeln.
- ACHTUNG:** Bei einer Verwendung im öffentlichen Bereich sind eine tägliche Prüfung und Kontrolle empfohlen!

Herstellungsdatum dieses Produktes:

Stand: 03 | 2020

**WICHTIG!** Für späteres Nachschlagen aufbewahren. Sorgfältig lesen.  
**NOTE!** Please retain this information for future reference. Read carefully.

## Assembly instruction for:



**KAWAsimplex**



**KAWAHPL**


**Our products comply with the GUV standards and are TÜV certified**

Dear customers,  
You have been given the completely assembled nappy wallchanger.  
Further parts are:

- 1x metal rail for the wall mounting
- 1x changing mat (already inside the wallchanger)
- 2x security screws
- 1x Allen keys
- 1x acrylic shelf

Additional for **KAWAHPL**

- 1x acrylic shelf (2 all together)
- 16x metal pieces for the acrylic shelf support



wall metal rail



changing mat

### Carrying out the assembly:

- Drill the holes for attaching the metal rail. As there are many different walls (timber, concrete, clay etc.) it is important that you use the correct dowel for your wall. Kindly ask a skilled worker or a DIY Market about the correct fitting material.
- We recommend a working height of 95 cm (floor/open changing flap) see also: [www.timkid.com/service](http://www.timkid.com/service)
- Hang the wallchanger into the metal rail and fix it with the two security screws.  
(the holes are in the back of the body part)

For **KAWAHPL** note the following:

- Put in the acrylic shelves (please remove the protective foil first)
- Please note that a metal shelf support must be placed on the left and right side in front of an acrylic shelf to secure the shelf.

### Please note!

- **Your child may never be allowed to lie on the changing table unobserved!**
- Please check the tightness of all assembled parts regularly.
- Please avoid direct heat near the changing table (as electric heaters or gas-fired ovens).
- Recommended for children up to 15 Kg (maximum weight 50 Kg).
- Additional parts or replacement parts are only available through timkid company.
- Please do not use the wallchanger if any part is broken or missing.
- Cleaning instructions for wood and laminate surfaces and the changing mat: wipe damp, possibly using standard disinfectant.
- **Note!** Used in a public area a [daily check is recommended](#).

**Date of production:**

version: 03 | 2020